

**STANDARD OPERATING PROCEDURE  
FOLEY PILOT PLANT**

**TITLE:** Biomass Acid Soak Preparation

---

**AUTHOR:** Ismael U. Nieves  
**APPROVALS:** Process Change Committee  
HHSM

**DATE:** March 29<sup>th</sup>, 2011  
**DATE:**  
**DATE:**

---

**CONTENTS**

- A. Scope**
- B. Safety and Training Requirements**
- C. Related Documents and SOPs**
- D. Preparation/Materials/Equipment**
- E. Detailed Procedure**
- F. Data Archival and Analysis**
- G. Tickets**

## A. Scope

This procedure describes the methods to prepare the acid soak solution for the biomass.

## B. Safety and Training Requirements

Acid resistant gloves and eye protection are required when dealing with acid solutions.

## C. Related Documents and SOPs

1. Biomass preparation SOP
2. OHAUS 5000 Series Xtreme W manual
3. Denver Instruments balance operation manual

## D. Preparation/Materials/Equipment

1. 30-gal drums
2. 1-L plastic beaker
3. OHAUS 5000 Series Xtreme W balance
4. Denver Instruments balance operation manual
5. 85% phosphoric acid solution
6. Rubbermaid Roughneck 25 gal storage bin

## E. Detailed Procedure

1. Calculate the amount of bagasse needed:

$$kg \text{ biomass needed} = \frac{(\# \text{ shots}) * \left( \frac{0.5 \text{ kg DW}}{\text{shot}} \right)}{\%DW * 0.8}$$

2. Make sure that enough bagasse has been prepared using the Biomass Preparation SOP.
3. Calculate the amount of acid solution to be prepared:

$$kg \text{ soak solution} = kg \text{ biomass needed} * \%DW * \left( \frac{14 \text{ kg solution}}{kg \text{ DW}} \right)$$

4. Calculate the amount of acid to be added:

$$kg \text{ acid to be added} = \frac{kg \text{ acid solution} * \text{concentration acid desired}}{\text{assay concentration of 85\% acid solution}}$$

5. Calculate the amount of water needed:

$$kg \text{ water needed} = kg \text{ acid solution} - kg \text{ acid added} - kg \text{ moisture}$$
$$kg \text{ moisture} = kg \text{ biomass needed} * \%DW$$

6. Prepare the soak solution:

- a. If  $kg \text{ biomass needed} * \%DW > 4.5 \text{ kg}$ , divide the biomass and soak solution in more than one drum.
- b. Add the water to the 30-gal drum(s) by weight using the OHAUS 5000 Series Xtreme W balance.
- c. Weight the acid using a 1-L plastic beaker and a Denver Instruments balance and add to the drum(s).

7. Weight the biomass needed into a Rubbermaid Roughneck 25 gal storage bin using the OHAUS 5000 Series Xtreme W balance.
8. Put a lid on the drum with the soak solution and on the bin with the biomass.

**F. Data Archival and Analysis**

Record the data in the Acid Soak Preparation Log and store in the Batch Log Book.

## G. Tickets

### Acid Soak Preparation Log

Date	<hr/>
%DW Prepared Biomass	<hr/>
Total Biomass Needed(kg)	<hr/>
Total Soak Solution (kg)	<hr/>
Number of Drums	<hr/>
Acid Assay Concentration (%)	<hr/>
Acid/Drum (kg)	<hr/>
Water/Drum (kg)	<hr/>
Biomass/Drum (kg)	<hr/>